

BH43 WIRE COUNTER



MWC - 2 Mechanical Drill Hole Wire Counter

- standard 3 decimeter circumference sheave
- machined to match client's cable
- mechanical counter in meters and decimeters
- ease of securing to drill collar with 3 bolts
- allows clear access of tools into the drill hole
- carrying handle

Options: 5 decimeter sheave with magnetic encoding for interfacing to the EWC series of electronic counters



PSO6-LCM Counter Sheave

- inexpensive direct reading mechanical sheave
- 450 Kg breaking strength
- fabricated from plastic with a nylon sheave
- unit is an up/down counter to 99,999 meters

Suggested Uses: Suitable for trace metal water sampling



EWC-3 Electronic Wire Counter

- stand alone up/down cable measuring system
- 4 digit LCD, 0.5" size, count to 999.9, count indicator
- automatic and manual direction control function
- works with magnetic encoded metering wheel such as PSO6 sheave, or your present block can be easily modified

EWC-4 Electronic Wire Counter with RS232

- measures cable, speed, and distance
- data output via RS232 for use by computer management systems